



Born To Win Protection Serum  
VIII-1.138.07A

<i>Phase</i>	<i>Material Name</i>	<i>US INCI</i>	<i>Supplier</i>	<i>% Material</i>
A	Deionized Water	Water	N.A.	82.12
A	Keltrol T Plus	Xanthan Gum	CP Kelco	0.30
B	Euxyl K 712	Sodium Benzoate Potassium Sorbate Water	Ashland	0.80
B	<b>MultiMoist CLR™</b>	Fructooligosaccharides Beta Vulgaris (Beet) Root Extract Water	CLR	3.00
B	<b>CutiGuard CLR™</b>	Betaine Sucrose Hydrolyzed Rhodophyceae Extract Water	CLR	3.00
B	Puricolor Blue ABL9-X FDA (0.2%)	Water Acid Blue 9	BASF	0.08
B	NaOH (32%)	Water Sodium Hydroxide	N.A.	0.10
B	<b>AnnonaSense CLR™</b>	Annona Cherimola Fruit Extract	CLR	3.00
C	Miglyol 829 ECO	Caprylic/Capric/Succinic Triglyceride	IOI Oleo	6.50
C	Myritol 318 MB	Caprylic/Capric Triglyceride	BASF	1.00
C	Perfume Everybody	Fragrance	Voegele	0.10
				<b>100.00</b>

**Operating Instructions**

Mix A and stir until completely dispersed. Add B in this order and adjust pH value to 5.2. Premix C and add it to AB while stirring slowly.

Directions for use:

Take a few drops of the serum and gently massage into the skin.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - [www.clr-berlin.com](http://www.clr-berlin.com)