

Ease Your Mind Serum VIII-6.138.02A

Phase	Material Name	US INCI	Supplier	% Material
4	Deionized Water	Water	N.A.	65.52
Д	Trisodium Citrate Dihydrate	Sodium Citrate	Merck	0.26
4	Microcare SB	Water Sodium Benzoate Potassium Sorbate	THOR	0.60
Д	Verdessence Xanthan	Xanthan Gum	BASF	0.20
В	MultiMoist CLR™	Fructooligosaccharides Beta Vulgaris (Beet) Root Extract Water	CLR	3.00
В	AnnonaSense CLR™	Annona Cherimola Fruit Extract	CLR	3.00
В	CutiGuard CLR™	Betaine Sucrose Hydrolyzed Rhodophyceae Extract Water	CLR	3.00
В	NaOH (10%)	Water Sodium Hydroxide	N.A.	0.12
С	Eutanol G	Octyldodecanol	BASF	8.00
С	Cetiol LC	Coco-Caprylate/Caprate	BASF	4.00
С	Cetiol C 5C	Coco-Caprylate/Caprate	BASF	12.00
С	Aromatic Charmomile Herbs Extract Blend N28924	Available on request	Carrubba	0.25
С	Carrot Oil CLR	Glycine Soja (Soybean) Oil Daucus Carota Sativa (Carrot) Root Extract Beta-Carotene Tocopherol	CLR	0.05
				100.00

Operating Instructions

Mix A until uniform. Add B in this order to A and stir. Premix C and add to AB.

Directions for use:

Shake before use. Take a few drops of the serum and gently massage into the skin.

 $The \ recommendations \ and \ formulations \ given \ are \ based \ on \ our \ knowledge \ and \ experience \ in \ the \ field \ of \ technical \ application.$

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com