



Ease Your Mind Serum 2
VIII-6.148.01A

<i>Phase</i>	<i>Material Name</i>	<i>US INCI</i>	<i>Supplier</i>	<i>% Material</i>
A	Deionized Water	Water	N.A.	65.40
A	Trisodium Citrate Dihydrate	Sodium Citrate	Merck	0.36
A	Euxyl K 712	Sodium Benzoate Potassium Sorbate Water	Ashland	0.60
A	Verdessence Xanthan	Xanthan Gum	BASF	0.20
B	DayMoist CLR™	Water Hydrolyzed Corn Starch Beta Vulgaris (Beet) Root Extract	CLR	3.00
B	CutiGuard CLR™	Betaine Sucrose Hydrolyzed Rhodophyceae Extract Water	CLR	3.00
B	AnnonaSense CLR™	Annona Cherimola Fruit Extract	CLR	3.00
B	NaOH (32%)	Water Sodium Hydroxide	N.A.	0.10
C	Eutanol G	Octyldodecanol	BASF	8.00
C	Cetiol LC	Coco-Caprylate/Caprates	BASF	4.00
C	Cetiol C 5C	Coco-Caprylate/Caprates	BASF	12.00
C	Aromatic Mango Extract Blend N36009	Available on request	Carrubba	0.25
C	Carrot Oil CLR	Glycine Soja (Soybean) Oil Daucus Carota Sativa (Carrot) Root Extract Beta-Carotene Tocopherol	CLR	0.08
				99.99

Operating Instructions

Mix A until uniform. Add B in this order to A and stir. Premix C and add to AB.

Directions for use:

Shake before use. Take a few drops of the serum and gently massage into the skin.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application.

They are, to the best of our belief, correct, but are offered without obligation.

Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.

This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.

CLR - Chemisches Laboratorium Dr. Kurt Richter GmbH - www.clr-berlin.com